

## Description

### METHOD AND APPARATUS FOR ASSAYING WOOD PULP FIBERS

#### Related Application

5 A claim of priority is made based on our provisional application Serial No. 60/450,306, filed February 27, 2003, and entitled Method and Instrument to Measure Single Fibers Properties by Application of Fluorescent Stains. This provisional application is hereby incorporated herein by this  
10 specific reference.

#### Technical Field

This invention relates to the provision of a method and apparatus for using fluorescent stained wood pulp fibers and  
15 a light beam to analyze and measure properties of interest in the wood pulp fibers. More particularly, it relates to the provision of a method and apparatus for determining chemical properties of the wood pulp fibers, for measuring geometric properties such as fiber length and shape, and for assessing  
20 the uniformity of wood pulp used in the manufacture of paper.

#### Background of the Invention

Wood fibers are the building blocks of paper and pulp products. Typically, properties of fibers, especially chemical  
25 properties, are measured on a macroscopic pulp sample that contains millions of fibers. While this information is essential to run unit operations in the mill, it is not sufficient to produce a final product with optimal properties. To truly optimize the performance in the pulp and paper mill  
30 requires that critical properties be measured on the single fiber level. With single fiber measurements, the uniformity (as well as the average values) of critical variables may be optimized and controlled. The result will be a globally optimized product that will have superior performance over that  
35 product which is controlled only by using averages of critical properties.

Instruments are available on the market today that can measure the geometric properties of single pulp fibers. These instruments can measure fiber length, coarseness, and fiber shape. In addition, some claim to be able to measure cell wall thickness. Mills routinely use these analyzer to assess and optimize the fiber's geometric properties to make the grade of paper currently being produced on their paper machine. Mills typically have fiber geometry specifications that include both average fiber properties as well as something about the uniformity of that fiber property.

An object of the present invention is to provide an apparatus and method that can measure fiber geometry characteristics, both the averages and the distributions, and critical chemical properties of the single fibers, such as lignin content (kappa number) or fiber charge. There is no instrument presently available that can measure this full suite of important fiber properties. It is also an object of the present invention to provide an apparatus and method by which paper makers will be able to correlate single fiber properties, such as comparing the relation between Kappa number and fiber shape, and, most importantly, develop relationships that allow them to determine the original profile of fiber properties and produce desirable grades of paper on their paper machine.

#### Brief Summary of the Invention

The present invention includes preparing a pulp fiber sample to be analyzed. The preparation method comprises preparing a fluorescent stain solution, adding a predetermined amount of pulp fibers to a predetermined amount of the stain solution; and mixing the pulp fibers and the stain solution to disperse the pulp fibers in the stain solution and create a slurry. Then, a pulp fiber solution is removed from the slurry and mixed with a second solution to form a pulp fiber suspension. Preferably, the second solution is a bleach. Preferably also, dilution water and bleach are present in an amount sufficient to permit reaction of the bleach with the stain in solution to an extent desired without an undesirable

amount of reaction of the bleach with stain that is bound to the pulp fiber.

Another aspect of the invention is the provision of a method of analyzing a pulp fiber sample. In preferred form,  
5 a flow cell is provided. The flow cell includes a passageway having an inlet, an outlet, and a region between the inlet and the outlet that has a transparent wall. A pulp fiber sample that includes a pulp fiber and a fluorescent stain bound to the pulp fiber is directed into the inlet of the flow cell, and  
10 from said inlet into the region between the inlet and outlet that includes the transparent wall. While the pulp fiber sample is in this region, a light source is used to direct light through the transparent wall into the pulp fiber sample to stimulate fluorescence from the pulp fiber sample while it  
15 is in the flow cell. Then, fluorescence from the pulp sample is analyzed to measure at least one property of interest in the pulp fiber sample.

A further aspect of the invention is to provide an apparatus for analyzing pulp fiber. Such apparatus comprises  
20 a flow cell that includes a passageway having an inlet, an outlet and a sample holding region between the inlet and the outlet that has a transparent wall. A conduit delivers a pulp fiber sample to the inlet of the flow cell. The pulp fiber sample flows through the inlet into the sample holding region  
25 of the flow cell. The pulp fiber sample includes pulp fiber and a fluorescent stain bound to the pulp fiber. A light beam projector is provided that includes a light source and a lens for producing a beam of light from the light source. The beam of light is directed to one side of a first dichroic mirror  
30 that extends approximately forty-five degrees with respect to the beam of light. The pulp fiber sample holding region of the flow cell is spaced from the dichroic mirror. An objective lens is positioned between the sample holding region of the flow cell and the first dichroic mirror and creates a  
35 substantially straight image path that extends at about a forty-five degree angle with respect to the first dichroic mirror and substantially perpendicular to the light beam. A

second dichroic mirror is positioned on the side of the first dichroic mirror that is opposite the light source, the focusing lens, the flow cell and the objective lens. The second dichroic mirror extends at an angle that is substantially perpendicular to the first dichroic mirror. In use, the image beam passes through the first dichroic mirror to the second dichroic mirror. A first wavelength portion of the image beam also passes through the second dichroic mirror. Another wavelength portion is reflected by the second dichroic mirror. A first camera is provided for recording the image that passes through the second dichroic mirror and a second camera is provided for recording the image that is reflected by the second dichroic mirror. Data obtained by the cameras is directed to a computer and in the computer is processes for determining properties of the pulp fiber sample.

Other objects, advantages and features of the invention will become apparent from the description of the best mode set forth below, from the drawings, from the claims and from the principles that are embodied in the specific structures and steps that are illustrated and described.

#### Brief Description of the Several Views of the Drawing

Like reference numerals used to designate like parts throughout the several views of the drawing, and:

Fig. 1 is a flow diagram of apparatus for preparing fiber samples for analysis, showing a flow cell in which a fiber suspension is imaged;

Fig. 2 is an enlarged scale view of the flow cell shown in Fig. 1;

Fig. 3 is a diagram of an optical system which is used to analyze fiber samples while they are in the flow cell;

Fig. 4 is a connectivity diagram illustrating how the hardware components of the system communicate with each other, including solid lines representing pulses and dashed lines representing continuous signals; and

Fig. 5 is a diagram illustrating an order of timing events.

### Detailed Description of the Invention

The fiber analyzer of the present invention includes a sample handling fluid system, shown by Figs. 1 and 2; an optical system shown by Fig. 3, and a data analyzing system shown by Fig. 4. The sample handling fluid system includes a flow cell having a sensing zone in which wood fiber samples can be illuminated as images, and pumps and conduits for causing a sample carrying liquid to flow into, through, and out from the sensing zone. The optical system includes a light source for illuminating the fiber samples while they are in the sensing zone of the flow cell, and apparatus for recording fluorescent images of the fibers. The data analyzing system operates to convert the recorded images into useful data.

Referring to Fig. 1, a container 10 includes stained wood pulp fibers. A container 12 contains dilution water and bleach. A suitable pump 14 (e.g. a gear pump) removes the solution of dilution water and bleach from container 12 and delivers it through a conduit 16 that leads to the inlet 18 of a flow cell 20. The relative flow rates of fibers and bleach are controlled to achieve a specific background fluorescence. Pump 14 pulls stained fibers out from the container 10 and admixes them with the solution from container 12 in the conduit 16. The suction created from pump 14 may, by way of example, be about 30 ml/min.. The dilution water and bleach solution is removed from container 12 at this rate and mixes with the fiber sample in the conduit 16 upstream of the inlet 18 leading into the flow cell 20. In the preferred embodiment, the solution from container 10 mixes with the stained fiber sample in a tee union positioned approximately two inches in front of the inlet 18 leading into the flow cell 20. After mixing, the sample/solution mixture enters into the flow cell 20 and for a while is in an imaging zone 22 that is between the inlet 18 and an outlet 24. The effluent from the flow cell 20 is directed into a filter 26 in which the fibers are filtered from the liquid, such as by use of a 5  $\mu$ m cartridge filter, and the liquid is pumped out of the system by use of a second pump 28 (e.g. a gear pump). The outlet of the pump 28 leads into a

prime tank 30 (e.g. a 500 ml tank). Tank 30 functions to ensure that the pump 28 will not lose its prime when the system is shut off. The liquid exiting the tank 30 flows to a drain 32. By way of example, the tubing in the system shown by Fig. 1 may be 1/4 inch OD polyethylene tubing and the fittings may be 1/4 inch polypropylene fittings.

An enlarged scale view of the flow cell 20 is shown by Fig. 2. Flow cell 20 includes a gasket 34 that is sandwiched between a piece of plexiglass 38 and a window cut from a microscope slide 36. The fiber sampling containing solution enters and exits through the inlet 18 and the outlet 24 that are formed in the member 38 of the flow cell 20. A channel is formed in the member 38. This channel may measure about 500  $\mu\text{m}$  deep, about 3 cm long and about 1 cm wide. The inlet 18 leads into one end of the channel and the outlet 24 leads out from the opposite end of the channel. The inlet opening 18 and outlet opening 24 are threaded for receiving a fitting (not shown) used to connect tubing to the member 38. In Fig. 2, the fiber stream is designated FS. In Fig. 2, the fiber stream FS is shown in space. In reality, a first tubing (not shown) is connected to the inlet 18 by a first fitting (not shown). A second tubing (not shown) is connected to the outlet opening 24 by another fitting (not shown). The channel is formed in a plexiglass member that is attached to member 38. The glass member 36 extends over and covers the open side of the channel when the members 38, 36 are together. The gasket 34 is an annular member and it surrounds the channel and seals its ends so that there is no leakage.

A negligible amount of fluorescence is observed from the plexiglass on the back of the flow cell 20. It is desirable to keep the flow cell fluorescence at a low level. Background fluorescence from the stain in solution can present problems if care is not taken. In order to obtain good measurements of fluorescent particles in the sample, the solution fluorescence must be reduced to a permissible level. A first way of doing this is to keep the gasket thickness as thin as possible without creating plugging problems in the channel. Secondly,

according to an aspect of the invention, a small amount of bleach is added to the dilution water that is mixed with the stained fiber stream upstream of the analysis zone 22 in the flow cell 20. The bleach is added an amount sufficient so that  
5 the stain in solution reacts with the bleach must faster than the reaction of the bleach with the stain bound to the fiber. That is, the bleach is present in the dilution water in an amount sufficient to permit reaction of the bleach with the stain in solution to an extent desired without an undesirable  
10 amount of reaction of the bleach with stain that is bound to the pulp fiber sample.

An additional precaution can be taken to control the reaction of fiber bound stain with bleach. Rather than bleaching all of the background fluorescence with an  
15 uncontrolled excess of bleach, the background fluorescence is kept at a low level with feedback control of the pump 22. The bleach concentration in solution is quickly reduced by this control before much bound stain can react with the bleach. A simple proportional/integral controller will provide the amount  
20 of control performance that is desired.

The optical system resembles a modern fluorescence microscope. Epi-illumination is used to minimize excitation light pollution in the fluorescence images. An extended path length is used to fit all of the necessary filters between the  
25 objective and imaging lenses.

Referring to Fig. 3, the apparatus that is illustrated includes a suitable light source 40, e.g. a xenon strobe lamp, which outputs light from the ultraviolet to infrared wavelengths. This light passes through a blue light filter 42  
30 which removes any light outside of the desired range for excitation. A dichroic mirror 44 is positioned to reflect the excitation light to an objective lens 46 that focuses the light onto the fibers in the flow cell 20. A "dichroic" mirror reflects some wavelengths of light and transmit the remaining  
35 wavelengths of light. The excitation light stimulates fluorescence from the stained fibers in the flow cell 20. The fluorescent light is then collimated by the objective lens 46.

All of this light then passes back through the excitation dichroic filter 44 onto a fluorescence splitting dichroic filter 48. One target wavelength (e.g. red) passes through a cutoff filter 50 and then to the imaging lens 52 where it is  
5 focused through the cameras IR filter onto a CCD 54. Light of a different wavelength (i.e. green light) is reflected by the fluorescence splitting dichroic member 48 to and through a bandpass filter 56 and then onto an imaging lens 58 which focuses the light on a green CCD.

10 By way of example, a kappa measurement will be described in which the sample is stained by use of an Acridine Orange stain. The blue pass filter 42 removes any light outside of the 420 nm to 490 nm band. A dichroic mirror 44, centered at 500 nm, is used to reflect the blue light onto the objective  
15 lens 46 where it is focused onto the fibers in the flow cell 20. The blue excitation light stimulates fluorescence from the Acridine Orange in the flow cell. The fluorescent light, which has wavelengths between 500 nm and 730 nm (green to red range), is collimated by the objective lens 46. The green and red  
20 light then pass back through the excitation dichroic filter 44 onto the fluorescence splitting dichroic filter 48 centered at 580 nm. Red light passes to the red cutoff filter (long pass at 590 nm), and then to the imaging lens 50 where it is focused through the cameras infrared filter (low pass at 680 nm) onto  
25 the red channel CCD 54. The green fluorescence, which was reflected at the fluorescence spinning dichroic member 48, passes through a green pass filter (510 nm to 570 nm), and is then focused by an imaging lens 58 onto a green channel CCD 60.

Optical magnification in the illustrated system is about  
30 0.64X. This is set by the ratio of the imaging lens focal length to the objective lens focal length. The objective lens is a 55 mm focal length lens designed for a 35 mm camera. The imaging lenses are two identical video lenses with 35 mm focal lengths. At this magnification, a CCD pixel is 13 $\mu$ m x 13  $\mu$ m,  
35 and the entire 400 by 400 pixel image covers 0.5 cm x 0.5 cm. This size is large enough that most fibers are not cut off by the edge of the image.

Light collection efficiency must be maximized in this system in order to get a reasonable signal to noise ratio in the CCD cameras. It was necessary to use two inch filters to keep the collimated light path as wide as possible. The result of the large diameter lenses and filters is that the system has a small depth of focus of about 500  $\mu\text{m}$ , and loss of intensity at the image edges to about 60 percent of the maximum (vignetting). The depth of focus is not a significant problem because the flow cell must be narrow in order to minimize the background fluorescence. Image vignetting is corrected before the images are processed.

Two simultaneous images, one from each camera, timed with a flash, must be captured and then processed to extract a particle fluorescence ratio. Typically, two wavelengths are required. One wavelength is specific for the property being measured and the other wavelength is a reference stain that corrects the image intensity with respect to general variables that can effect fluorescence intensity such as cell wall thickness. Mostly off-the-shelf components along with some custom built hardware accomplish this task. A PC fitted with frame grabbers and a data acquisition card controls the entire process. A LabView program controls the computer task involved in timing and image acquisition.

Fig. 5 is a conductivity diagram showing how all of the hardware components communicate. The solid lines in Fig. 5 represent pulses. The dashed lines represent continuous signals.

Video synchronization is the first step to making the instrument work. An external sync generator provides the same type sync signal to the two cameras. The sync generator has horizontal sync outputs providing negative pulses at 15.625 kHz with a pulse width of 4.7  $\mu\text{sec}$ . The vertical sync outputs are negative pulses at 25 Hz with a width of 450  $\mu\text{sec}$ . Using these sync signals, the two cameras operate together, including shuttering at the same time.

The instrument operates semi-synchronously. The flash occurs only when the computer PC is ready to collect another

frame, and only that frame is transferred into computer memory, but all the action is timed from the vertical sync signal. The flash 62 requires additional timing, because the flash 62 must be triggered during the correct frame, and during the 1/4000th of a second that the shutter allows the camera 64 to integrate. Figure 5 illustrates the order of timing events. The computer PC sends a pulse to the sync generator/timing box 70 (Fig. 4) when it is ready to capture an image. The timing box 70 waits for the first vertical sync and then sends a 20 msec delayed high pulse to the triggers of the two frame grabbers (halfway between the first and second vertical sync pulses). On the second vertical sync pulse, the timing box sends a strobe trigger to the computer's data acquisition card (DAC). The (DAC) adds a 1750  $\mu$ sec delay to the trigger and then passes it to the flashlamp trigger input. The delay is necessary to cause the flash to occur during the 1/4000th sec window that the camera shutters are allowing the CCD's to integrate light. After the integrated frames from the two color channels are transferred to analog video signals, the awaiting frame grabbers in the PC digitize the signals and pass the information into the computer memory where it can be accessed within the LabView environment.

Once the images are present in computer memory, processing begins to take place. The first step in image processing is correction. The dark-current image is subtracted from the raw image. Then the raw images from each color channel are multiplied by the vignette correction images that flatten the fields and calibrate the color sensitivity of the two cameras. A quick binary threshold is performed, and the number of bright pixels in the image is counted by summing the binary image intensity. If there are too few bright pixels to make up a fiber, the image is dumped and the computer goes back into acquisition mode.

If there are particles in the images, the corrected images are passed for further analysis. Background estimation is performed using a low pass filter. This separates the fluorescent stained fibers from the solution and flow cell

fluorescence. The background is subtracted from the corrected image leaving fibers and noise, and then a threshold is applied to locate the fibers. Then a subroutine quantifies the mean red and green intensities, perimeter, and area of the objects.

5 The final processing step is classifying the particle shapes. A subprogram performs an algorithm that yields kink and curl indices of the fibers. A special filter is then applied to each object, identifying endpoints in the object. Any object with more than two ends is flagged as a fiber clump. The data  
10 for each fiber are catalogued into an array of fiber records, and the program loops back to acquisition mode. After the user stops acquisition, fiber data are saved as an array in a spreadsheet file.

The following is an overview of the staining and analysis  
15 protocols. Analysis involves preparing the stained fiber sample, and running the instrument.

- 1) Make up a stock stain solution.
- 2) Add about 0.1 g OD of pulp to 1 liter of the stain  
20 solution, and disburse the fibers by mixing in a blender.
- 3) Place the slurry in a one-liter beaker and allow it to stir for ten minutes with a magnetic stirrer. After ten minutes, the sample is ready for analysis.

The instrument described above can be used to make the  
25 basic chemical and morphological measurements on pulp fibers. The wavelengths used in the analyses depend on the stains being used and may be easily modified to get the best signal to noise ratio with whatever dye has been selected. The instrument can also be easily modified to measure signal intensity at more  
30 than two wavelengths if such measurements were needed. For example, if you were measuring multiple chemical properties on fibers simultaneously.

The following is a list of the components that are shown in Fig. 3:

5	Red CCD	54	#XC8500CE/BW Camera Module	Sony 550 Madison Avenue New York, NY 10022 888-476-6972
10	Red Lens	52	#HF35A-2M1/BW Camera Module Lens	Sony
15	Red Cutoff Filter	50	#03 FCG 098/Red Filter #03 FCG 101/Red Filter	Melles Griot 55 Science Parkway Rochester, NY 14620 585-241-2279
20	Dichroic 2	48	#585 DCXR/Dichroic #2	Chroma Tech. 74 Cotton Mill Hill Brattleboro, VT 05301 1-800-824-7662
25	Green Cutoff Filter	56	#D525 50m/Green Filter	Chroma Tech.
30	Green Lens	58	#HF35A-2M1/BW Camera Module Lens	Sony
35	Green CCD	60	#XC8500CE/BW Camera Module	Sony
40	Dichroic 1	44	#490 DCLP/Dichroic #1	Chroma Tech.
45	Blue Filter	42	#D455 70m/Blue Filter	Chroma Tech.
50	Converging Lens	41	#H32-982/2in Dia 6in FL Lens	Edmund Industrial Optics 101 East Gloucester Pike Barrington, NJ 08007-1380 800-363-1992
55	Arc Lamp	40	OSRAM 5000K Arc Lamp	OSRAM SYLVANIA 100 Endicott Street Danvers, MA 01923 978-777-1900
60	Objective Lens	46	Carl Zeiss/Planar 1,4/50	Carl Zeiss Carl Zeiss Str. 4-54 73447 Oberkochen Germany (0049) 7364-20 6175

The instrument can also be easily modified to handle larger on smaller particles. This would increase the applicability of the instrument in the paper mill and make it useful for industries such as pharmaceuticals and food processing. To image smaller or larger particles would require minor modifications to the flow cell and the instrument optics.

The illustrated embodiment is only one example of the present invention and, therefore, is non-limitive. It is to be understood that many changes in the particular structure, materials, and features of the invention may be made without departing from the spirit and scope of the invention. Therefore, it is our intention that our patent rights not be limited by the particular embodiment that is illustrated and described herein, but rather be determined by the following claims, interpreted according to accepted doctrines of claim interpretation, including use of the doctrine of equivalents.